



Image: State of the state



## WHAT'S INCLUDED IN THE BOX?

Included in the box will be everything you need to complete installation. We provide all of the posts, fasteners, cable, cable end fittings, tools, and our patented top rail bracket. If you have concerns/questions about anything with regard to your order, please feel free to call us anytime at **+1 (855) GET-CITY**. WATCH OUR STEP-BY-STEP INSTALLATION VIDEOS (INCLUDES MORE TIPS & TRICKS)

citypost.com/installation

SIMPLE & AFFORDABLE CABLE RAILING

CITYPOST

SIMPLE · AFFORDABLE

## THE ORDERING PROCESS

1 DEFINE SEGMENTS



The first step is to measure the distance of the railing, writing down the details for each segment. Segments are the continuous sections of a railing (either horizontal or stairs). Specifications are listed below.







Base/Surface Fascia/ Mount Front Mount Lag Bolts

Concrete

Anchors



## **INSTALLATION**

CityPost Cable railing installs in just 3 EASY STEPS.

## 1 LAYOUT & INSTALL POSTS

CityPost sends enough posts for a maximum center to center distance of 60" - measure and lay posts out on deck in desired locations.

Once layout is complete install posts with the CityPost supplied fasteners

#### For corners, CityPost offers three options:

1. Cable starts and stops at each corner. (Double corner posts)



- **2.** Cable turns the corner for a continuous look (Double corner posts)
- **3.** Terminate two segments into a single corner post

Check that the posts are level before drilling. When you are ready to install anchors, pre-drill with a 3/32" bit (1/4" for concrete) and use the included bit to drive anchors.

# 2 LAYOUT & INSTALL TOP RAIL

Plan your layout on a sheet of paper ahead of time.

#### **MEASURE TWICE, CUT ONCE!**

Use the fasteners supplied in your kit to secure the cut pieces of top rail to the patented CityPost top rail bracket.

## **3** INSTALL & TIGHTEN CABLES

CityPost always sends out at least 10% extra cable and a few extra fittings to ensure you're well supplied throughout the project.

### **TOP RAIL & TRANSITION SLEEVES**

CityPost stocks 1"x3" aluminum top rail as well as an array of transition sleeves to cover the corners once they have been cut.



To tighten cables all you need is a pair of vice-grip pliers and a 10mm wrench!



type of top rail material you'd like use!

#### **ACCIDENTALLY SCRATCHED?**

Mistakes happen. Call us at +1 (855) GET-CITY for a touch-up kit.